



EMD DIESEL ENGINE SPARE PARTS



HALTIC ENDUSTRY CO.




WABCO



Gardner Denver



1- STARTER MOTOR ASSEMBLY




Ref.	Part Number	Qty	Description
	10478829	1	MOTOR ASSEMBLY .. Starter - 64VDC The following items, 2 thru 24, are not shown.
-2	1115567	1	SWITCH ASSEMBLY .. Solenoid - 32Volts
-3	1967353	1	FRAME ASSEMBLY .. Commutator end
-4	1967349	1	ARMATURE ASSEMBLY .. Motor
-5	1047586	1	FRAME AND FIELD ASSEMBLY
-6	1047553	1	HOUSING ASSEMBLY .. Lever
-7	830620	1	DRIVE ASSEMBLY .. Clutch
-8	1959604	1	PLUNGER, SPRING & BOOT ASSEMBLY
-9	1936466	1	SPACER
-10	1953237	1	WASHER
-11	1911126	2	RIVET
-12	1047553	4	SCREW



Haltic Endüstri İthalat İhracat ve Ticaret limited Sirketi.

-13	1945860	1	SEAL .. O-ring
-14	1049963	1	BOLT
-15	9412305	1	NUT
-16	1979600	1	LEAD ASSEMBLY
-17	1945356	4	PLUG .. Inspection
-18	1964857	4	GASKET .. Plug
-19	1968998	1	SCREW
-20	1979451	2	NUT
-21	1979365	1	NUT ASSEMBLY
-22	1047609	5	SCREW
-23	1049963	1	SCREW
-24	1906989	1	BRUSH ASSEMBLY .. Motor

2- SOLENOID SWITCH ASSEMBLY



Ref.	Part Number	QTY	Description
	1115567	1	SWITCH ASSEMBLY .. Solenoid-32Volts
-2		1	CASE ASSEMBLY .. Switch-Includescoil
-3	1967335	1	CONTACT ASSEMBLY .. Disc
-4	1948661	1	SPRING .. Contact return - Pushrod
-5	1979832	1	PLATE ASSEMBLY .. Switchterminal
-6	1979499	1	PLATE .. Terminal
-7	1953244	1	STUD .. Terminalbattery
-8	1906049	1	STUD .. Terminalmotor
-9	1979369	1	INSULATION .. Strip - Terminal stud
-10	1984705	2	INSULATOR .. Bushing - Terminal stud - 4holes
-10	1944836	2	INSULATOR .. Bushing-Terminal stud (Optional)
-11	1914647	2	WASHER .. Plain - Terminal stud
-12	1942969	2	BUSHING .. Insulating - Terminal stud
-13	9421427	2	WASHER .. Lock - Terminal stud
-14	9414418	2	NUT .. 1/2-13 terminal stud
-15	1979451	2	NUT ASSEMBLY .. Terminal stud - Includes washer



Haltic Endüstri İthalat İhracat ve Ticaret limited Sirketi.

-16	1906051	1	CLIP .. Terminal support
-17	1949368	1	INSULATOR .. Terminal stud - 5 hole
-18	1979776	2	TERMINAL PACKAGE .. Switch and ground
-19	10496037	1	GASKET .. Starter switch terminal plate
-20	9417496	4	SCREW ASSEMBLY .. Attaching cover terminal plate
-21	1840633	3	SCREW .. Attaching coil lead
-22	1979365	4	NUT ASSEMBLY .. Attaching cover terminal plate - Includes washer
-23	1972716	1	BUSHING .. Rod plunger guide